

MOJO

CRUMAR®

61

OPTIONAL LOWER MANUAL



USER'S MANUAL

www.crumar.it

SAFETY INFORMATION

- Do not open the instrument. The instrument can be opened and repaired only by qualified personnel. Unauthorized opening voids the warranty.
- Do not expose the instrument to rain or moisture.
- Do not expose the instrument to direct sunlight.
- Be careful not to infiltrate powders and liquids inside the instrument. Nor on the outside.
- If liquids get inside the unit, remove the power immediately to prevent the risk of electric shock and contact a service center as soon as possible.
- Do not clean using abrasive cleaners as they may damage the surface.
- Please keep all packaging in case you need to transport the instrument to a service center.

WARRANTY

- Crumar Lower Manual for Mojo 61 is subject to 12 months manufacturer's warranty.
- Warranty extensions are at the discretion of the retailer.
- Damages caused by misuse, improper maintenance or transportation are not covered by this warranty.
- During the warranty period, the customer is entitled to repair or replacement of any parts considered defective at no charge.
- The possible replacement of the entire product is at the manufacturer's discretion.

1. INTRODUCTION

The Lower Manual for Mojo 61 is an additional keyboard that turns the portable single-manual Mojo 61 into a complete dual manual organ console, giving the player the experience of a real combo organ setup adding the versatility of two different choices for different situations.

This additional keyboard is based on the same “waterfall” keybed as the Mojo 61 in order to preserve the integrity of the organ experience, resulting in a very natural feel for both manuals.

The system is perfectly integrated, allowing the player to control both manuals with just one set of drawbars without any particular complication. On the Mojo 61 control panel, press and hold the MODE button until the yellow LED marked “EXT-LOWER” lights up. This will keep the upper manual sound on the upper keyboard even when the LOWER button is active, allowing the player to adjust the lower manual drawbar registration using the physical drawbars.

2. CONNECTION AND MOUNTING PROCEDURE

Lay the Lower Manual on a keyboard stand, then place the Mojo 61 above it paying attention to the rubber feet, they must match the underlying holes so that the two pieces are firmly tied together.



Locate the MIDI ports on the back of the instruments and use one of the two provided special cables to attach the lower manual to one of the two MIDI IN ports of the Mojo 61. The cable carries both MIDI and Power by means of the two additional wires that are not used by the MIDI protocol.



The optional Half Moon Switch for controlling the Rotary Speaker simulation can be attached on the bottom front left of the lower manual.

PLEASE NOTE: THE HALF MOON SWITCH FOR THE DUAL MANUAL MOJO ORGAN IS NOT COMPATIBLE WITH MOJO 61.

3. SPECIFICATIONS

Technical specifications:

- power rating: power over midi.
- weight: 8 Kg / 17,6 lbs



Crumar Mojo 61 and Lower Manual for Mojo61 are digital Musical Instruments designed and built in Italy. All rights reserved.

All trademarks used herein are the property of their respective owners.
Crumar is a trademark owned by:

V.M. Connection
Via Pascoli, 44/A - 30020 Quarto d'Altino (VE) - Italy
www.Crumar.it

Last update: October 2017.